


PEMWE und AEMWE im Vergleich: Gemeinsamkeiten und Unterschiede


Dr. Natalia Levin

Mature technologies for water electrolysis

- 3 main technologies




- PEMWE and AWE market share




Strictly confidential - no passing on to third parties!

Proton exchange membrane water electrolysis (PEMWE)




- + Well developed technology
- + High flexibility
- + Flexible power level
- + High pressure H₂ production
- Critical raw materials (CRM)

Anion exchange membrane water electrolysis (AEMWE)



- + Flexible power level
- + Precious metal free catalysts
- Lower current densities



Alkaline Electrolysis (AWE)



- + Low costs
- + Established technology
- Lower current densities
- Lower H₂ purity
- Limited integration with renewables

Open challenges: PEMWE and AEMWE

PEMWE: Cost breakdown



Open challenges

PEMWE

Ir and Pt

- Costly (<10% cost full PEMWE system)
- Ir: production of Ir/Pt
- only 3 GW-7.5 GW annual PEMWE manufacturing capacity

PFSA-membranes

- Environmental concerns
- Sustainability issues
- Regulatory challenges

PTL/BPP: Ti(Pt-coated)

- Costly


AEMWE

PGM-free catalysts

- Main challenge for AEM


PTL/BPP: Ni or SS

Our research: From single cells to stacks in PEMWE and AEMWE



Strictly confidential – no passing on to third parties!


PEMWE: Reducing dependence on CRM → Ir




Strategies to reduce dependence on CRM

- Prevention or reduction of use
- Increasing efficiency
- Recycling

Ongoing development: Noble Metal free PEM Anode Catalyst via Electrodeposition



SEM




Next steps

- Complement characterization
- Extend durability studies

PTL Anode: Pt/Ti felt, Catalyst Anode: (PGM-free): $\sim 8 \text{ mg cm}^{-2}$, (PGM-free dopant): 0.3 mg cm^{-2} , Nafion: 0.5 mg cm^{-2} , Pretreated Nafion[®]115 (thickness – $127 \mu\text{m}$), PTL Cathode: Freudenberg H23, Catalyst Cathode: (Pt/C): 0.2 mg cm^{-2} , 5 cm^2 cell, Electrolyte: pre-heated DI H_2O , Experiment performed at $60 \text{ }^\circ\text{C}$.


AEMWE: Alternatives for cost reduction



Cathode catalyst: Pt-based catalyst, as well as PGM-free ones, are widely used


→ Promising cost reduction

IGF N-AEMEL Project: Noble Metal free AEM Cathode Catalyst via Electrodeposition




SEM

Before testing



After testing




Next steps

- Complement characterization
- Extend durability studies

PTL Anode: Bekaert 20FP3, Membrane: Fumatech FAA-3-50, Catalyst Cathode: 0.2 mg cm⁻² Pt/C or Ni-S, PTL Cathode: Bekaert 20FP3, 5 cm² cell, Electrolyte: pre-heated 1 M KOH, Experiment performed at 60 °C.

AEMWE: The most critic component → AEM membrane





Membranes for AEMWE

- Durability
- Ionic conductivity

Comparison of commercially available membranes


AEM	$i @ 2 \text{ A cm}^{-2}$ V
Membrane 1	2.01
Membrane 2	2.03
Membrane 3	1.99
Membrane 4	1.96
Membrane 5	2.04



- Broad variability
- Still no standard


PTL Anode: Bekaert 20FP3, Catalyst Anode: blank, Membrane: various, Catalyst Cathode: 0.2 mg cm⁻² Pt/C, PTL Cathode: Freudenberg H23, 5 cm² cell, Electrolyte: pre-heated 1 M KOH, Experiment performed at 60 °C.

Our research: From single cells to stacks in PEMWE and AEMWE



Strictly confidential - no passing on to third parties!

PEMWE: Reducing dependence on CRM → PTL





- PTL: Ti(Pt-coated)**
- High cost
 - Develop alternative materials
 - Optimised structure ensure homogeneous distribution of H₂O to catalyst layer and gas removal

depends on porosity


IGF MetalFoil-PTL Project: Laser-based structuring of Ti foils

- Parameters: hole size, number of holes, distance between holes
- Precisely adjustable porosity




Electrochemical performance

- Higher 2D porosities (>1.24%) → Better water supply and O₂ removal
- Reduced mass transport resistance





PTL Anode: laser drilled Ti foil, PTL Cathode: Freudenberg H23, CCM: Pretreated Nafion®115 (thickness – 127 μm), anode cat. Layer (IrO_x): ~0.3 mg cm⁻², cathode cat. layer (Pt/C): 0.2 mg cm⁻², 5 cm² cell, Electrolyte: pre-heated DI H₂O, Experiment performed at 60 °C.

AEMWE: Optimizing selection of PTL




- PTL**
- Alkaline environment enables use of non-noble metal-based materials
 - Ni-based or Stainless steel
 - Different structures available

Stainless steel PTL



μ-CT




Surface Area* / $\mu m^2 \mu m^{-3}$:	87	10
Porosity / %:	60	69
Thickness / μm :	300	320

Felt stainless steel → better contact


PTL Anode: Bekaert 20FP3, Catalyst Anode: $2 mg cm^{-2} NiFe_2O_4$, Membrane: Fumatech FAA-3-50, Catalyst Cathode: $0.2 mg cm^{-2} Pt/C$, PTL Cathode: Freudenberg H23, $5 cm^2$ cell, Electrolyte: pre-heated 1 M KOH, Experiment performed at $60 \text{ }^\circ C$, *calculated via XRM.

AEMWE: Optimizing selection of PTL




- PTL** – Alkaline environment enables use of non-noble metal-based materials
- Materials: Ni-based or Stainless steel
- Different structures available

Felt PTL: Different materials




SEM

Nickel



Nickel + LDH



Ni-based PTL + catalyst → better performance

PTL Anode: (SS) Bekaert 20FP3, (Ni) Bekaert 2Ni18-050, Membrane: Fumatech FAA-3-50, Catalyst Cathode: 0.2 mg cm^{-2} Pt/C, PTL Cathode: Freudenberg H23, 5 cm^2 cell, Electrolyte: pre-heated 1 M KOH, Experiment performed at $60 \text{ }^\circ\text{C}$.

Our research: From single cells to stacks in PEMWE and AEMWE



Strictly confidential – no passing on to third parties!

ZBT PEMWE Stack:

Development of a modular high-pressure electrolysis stack as a test platform for the qualification of materials and components

INNOKOM PEMWEST Project: Goals


- 5-10 cells, 100 cm² active, P < 35 bar
- Separator plates with/without flow structure
- Flexible concept for changing cell components/materials
- Easy to stack

Current status


- Functional stack build up with 3 cells
- Tests coming soon

Next steps



- Further developments (e.g. sealings, design)
- Adaptation for AEMWE (similar design, replace components)



- Plastic-based, t~1mm
- O-rings as gaskets




Anode sealing frame (back side)



Strictly confidential - no passing on to third parties!

Summary



Strictly confidential – no passing on to third parties!

Acknowledgements

Dr. Vimanshu Chanda
Frank Filusch
Fabian Graef
Sebastian Hirt
Miriam Hesse
Claus Irsa
René Jahn
Bastian Kaufmann
Mounir Kouachi
Dr. Jörg Karstedt
Lars Kühnemann
Amir Najafi
Bernd Oberschachtsiek
Dr. Susanne Palecki
Dr. Moritz Pilaski
Christina Schüring
Hesham Solh
Markus Sonnenberg
Pascal Sous
Ivan Radev



Thank you for your attention!

Dr. Natalia Levin

+49 203 7598 – 4282 / n.levin@zbt.de

WWW.ZBT.DE

